

NEW PRODUCT RELEASE

For Immediate Release
November 21, 2008

Contact: Applications Engineering

New DYMAX MD[®] Medical Device Adhesive Formulated with See-Cure Technology

DYMAX MD[®] Medical Device Adhesive 1201-M-SC is a new flexible adhesive designed for rapid bonding of a variety of rigid and flexible plastics typically used in the manufacture of medical devices such as reservoirs, tube sets, and catheters. The recommended substrates include PC, PET, PS, PU, PVC, and ABS. 1201-M-SC cures upon exposure to UV/Visible light in fractions of a second when exposed to high-intensity UV light, such as that produced by the DYMAX BlueWave[®] 200 Spot Lamp, enabling faster processing, greater output, and lower assembly costs. This adhesive is formulated with DYMAX's exclusive See-Cure Technology.

DYMAX adhesives that are formulated with the new See-Cure technology are bright blue in color in the uncured condition. This makes them easy to see on the surface of substrates, in deep wells, or when sandwiched between two layers of materials. Because the blue color is extremely visible, simple vision systems can be incorporated into assembly processes prior to curing in order to easily identify adhesive coverage and profile, resulting in greater efficiency and less scrap.

DYMAX Corporation - 318 Industrial Lane - Torrington, CT 06790 - Phone: 860-482-1010 - Fax: 860-496-0608 - E-mail: info@dymax.com - www.dymax.com

DYMAX Europe GmbH - Trakehner Strasse 3 - D-60487 Frankfurt am Main - Germany - Phone: 0049-69-7165-3568 - Fax: 0049-69-7165-3830 - E-mail: dymaxinfo@dymax.de - www.dymax.de

DYMAX UV Adhesives & Equipment (Shenzhen) Ltd - Unit 807, Talfook Building, No. 9 Shi Hua Road, Futian Free Trade Zone, Shenzhen, China 518038 - Phone: 86.755.83485759 - Fax: 86.755.83485760 - E-mail: dymaxasia@dymax.com - www.dymax.com.cn

DYMAX Asia (HK) - Unit 1006, 10/F., Camarvon Plaza, No. 20, Camarvon Road, T.S.T., Kowloon, Hong Kong - Phone: 852-2460-7038 - Fax: 852-2460-7017 - E-mail: dymaxasia@dymax.com - www.dymax.com.cn

DYMAX[®], Light Weld[®], Light-Welder[®], Multi-Cure[®], Ultra Light-Weld[®], MEDI-CURE[®], MD[®] and SpeedMask[®] are registered trademarks of DYMAX Corporation

But, See-Cure's blue color is only temporary. The adhesive's blue color becomes the visible indicator that identifies when sufficient light energy has been provided to the adhesive bond area to achieve full cure. As the adhesive cures, the blue color within the adhesive fades and ultimately turns clear upon full cure.

DYMAX Corporation is a leading technology-based company specializing in the formulation, manufacture, and service of advanced assembly adhesives, coatings, epoxies, masking resins, and light curing systems. This adhesive is in full compliance with the RoHS Directives 2002/95/EC and 2003/11EC.

For more information, contact DYMAX Corp., 318 Industrial Lane, Torrington, CT 06790; Phone: 860-482-1010; Fax: 860-496-0608; Toll Free: 1-877-DYMAX-MD (1-877-396-2963); e-mail: info@dymax.com or visit our website at www.dymax.com.

#

#

#

DYMAX Corporation - 318 Industrial Lane - Torrington, CT 06790 - Phone: 860-482-1010 - Fax: 860-496-0608 - E-mail: info@dymax.com - www.dymax.com

DYMAX Europe GmbH - Trakehner Strasse 3 - D-60487 Frankfurt am Main - Germany - Phone: 0049-69-7165-3568 - Fax: 0049-69-7165-3830 - E-mail: dymaxinfo@dymax.de - www.dymax.de

DYMAX UV Adhesives & Equipment (Shenzhen) Ltd - Unit 807, Talfook Building, No. 9 Shi Hua Road, Futian Free Trade Zone, Shenzhen, China 518038 - Phone: 86.755.83485759 - Fax: 86.755.83485760 - E-mail: dymaxasia@dymax.com - www.dymax.com.cn

DYMAX Asia (HK) - Unit 1006, 10/F., Carnarvon Plaza, No. 20, Carnarvon Road, T.S.T., Kowloon, Hong Kong - Phone: 852-2460-7038 - Fax: 852-2460-7017 - E-mail: dymaxasia@dymax.com - www.dymax.com.cn

DYMAX®, Light Weld®, Light-Welder®, Multi-Cure®, Ultra Light-Weld®, MEDI-CURE®, MD® and SpeedMask® are registered trademarks of DYMAX Corporation



CAPTION: DYMAX MD[®] Medical Device Adhesive 1201-M-SC is formulated with DYMAX's exclusive See-Cure™ Technology



P175

Technical data provided is of a general nature and is based on laboratory test conditions. DYMAX does not warrant the data contained in this bulletin. Any warranty applicable to the product, its application and use is strictly limited to that contained in DYMAX standard Conditions of Sale. DYMAX does not assume responsibility for test or performance results obtained by users. It is the user's responsibility to determine the suitability for the product application and purposes and the suitability for use in the user's intended manufacturing apparatus and methods. The user should adopt such precautions and use guidelines as may be reasonably advisable or necessary for the protection of property and persons. Nothing in this communication shall act as a representation that the product use or application will not infringe on a patent owned by someone other than DYMAX or act as a grant of license under any DYMAX Corporation Patent. DYMAX recommends that each user adequately test its proposed use and application before actual repetitive use, using the data in this communication as a general

DYMAX Corporation - 318 Industrial Lane - Torrington, CT 06790 - Phone: 860-482-1010 - Fax: 860-496-0608 - E-mail: info@dymax.com - www.dymax.com

DYMAX Europe GmbH - Trakehner Strasse 3 - D-60487 Frankfurt am Main - Germany - Phone: 0049-69-7165-3568 - Fax: 0049-69-7165-3830 - E-mail: dymaxinfo@dymax.de - www.dymax.de

DYMAX UV Adhesives & Equipment (Shenzhen) Ltd - Unit 807, Talfook Building, No. 9 Shi Hua Road, Futian Free Trade Zone, Shenzhen, China 518038 - Phone: 86.755.83485759 - Fax: 86.755.83485760 - E-mail: dymaxasia@dymax.com - www.dymax.com.cn

DYMAX Asia (HK) - Unit 1006, 10/F., Camarvon Plaza, No. 20, Camarvon Road, T.S.T., Kowloon, Hong Kong - Phone: 852-2460-7038 - Fax: 852-2460-7017 - E-mail: dymaxasia@dymax.com - www.dymax.com.cn

DYMAX[®], Light Weld[®], Light-Welder[®], Multi-Cure[®], Ultra Light-Weld[®], MEDI-CURE[®], MD[®] and SpeedMask[®] are registered trademarks of DYMAX Corporation

